




5812B with Aux
5810 no Aux

Locking Half Case Only
Locking Half Complete No Aux
Locking Half Complete with Aux
Interior Moulding
Power Contacts
Auxiliary Contacts
Rubber Cable Sleeve


5840
5810B
5812B
951D
952D
955D
LH-NK2



5806B with Aux
5804B no Aux

Charging Half Case Only
Charging Half Complete No Aux
Charging Half Complete with Aux
Interior Moulding
Power Contacts
Auxiliary Contacts
Rubber Cable Sleeve

5841
5804B
5806B
951D
952D
955D
LH-NK2






5818B with Aux
5816B no Aux

Locking Half Case Only
Locking Half Complete No Aux
Locking Half Complete with Aux
Interior Moulding
Power Contacts
Auxiliary Contacts
Rubber Cable Sleeve


5840G
5810BG
5812BG
951D
952D
955D
Lh-NK2




5812BG with Aux
5810BG no Aux


Mounting Half Case Only
Mounting Half Complete No Aux
Mounting Half Complete with Aux
Interior Moulding
Power Contacts
Auxiliary Contacts
Rubber Cable Sleeve

5842
5816B
5818B
951D
952D
955D
LH-NK2







951D
Interior Moulding




952D
Power Contacts




955D
Auxillary Contacts




LH-NK2
Rubber Cable
Sleeve




5842
Mounting Half



5840
Locking Half



5841
Charging Half



5840G
Locking Half
with Bracket